

OPEN GRILL CABIN 14.9 M²



www.vikingindustrier.com

PRODUCT DESCRIPTION

A combination of Scandinavian style and natural wood allows you to enjoy a cozy BBQ house. Due to its design and easy assembling the hut is extremely mobile and can be built in your garden, yard or campsite. This cottage will not endanger the landscape. The Grill cabin has an enclosed wall at the back, protecting against the wind. The open front allows you to enjoy the view and be in the fresh air.

Open Grill Cabin walls are made of rounded spruce boards. The support columns in front can be of two types: round and square. A roof is made of eight elements and covered with bitumen shingles (different colors can be selected: red, green and black). And there is a small porch with a roof at the entrance. Cabins are made from North spruce wood. North spruce is typically a creamy white, with a hint of yellow and/or red. Norway Spruce has a fine texture. The wall thickness is 45 mm.

The standard set includes a barbecue grill. There is a convenient wood- or charcoal-fired grill with a table around it inside the cabin. Also, one adjustable cooking platform and two special platforms for a kettle, frying pan, etc. can be found. Above the grill, there is an adjustable chimney.

Important! This Open Grill Cabin standard set is without a floor!



SPECIFICATION

People	10 persons
Timber	Spruce
Shape	Octagonal
Room	1
Inside area	14.9 m ²
Total height	3574 mm
Wall height	1330 mm
Roof thickness	18 mm
Wall thickness	45 mm
Window size	880 x 510 mm

STANDARD SET

Wall, roof panels from spruce;		
6 support wooden pillars;		
Roof covered with bitumen shingles of your selected color: red, green or black;		
Inside grill with cooking platforms;		
Table around the grill;		
Adjustable chimney;		
Two windows;		
3 benches inside (fixing to the wall).		

DELIVERY

Assembling time	7 hours
Size of pallets (LxWxH)	3.5 x 1.2 x 2.55 m
Weight	1300 kg

Grill Cabin is delivered to the customer **not assembled** but fully complete, with detailed assembly instructions and drawings, and packed on a pallet (KIT).

Two people can assemble Grill Cabin in 7 hours.

~ We pack all accessories on the same pallet if it is possible. Otherwise, all accessories will be packed on a separate pallet.

GRILL AND CHIMNEY SET



"Premium" 8-corner Grill and Chimney set



"Viking" Grill and Chimney



Standard 8-corner Grill and Chimney



Luxury Grill and Chimney



Without Grill and Chimney

OPTIONS

AVAILABLE ROOF COLOR





Black shingles

Green shingles



Red shingles

WALLS HEIGHT

- One extra board in wall (the height of board 145 mm)
- Two extra boards in wall

GRILL CABIN COLUMNS:





Round columns

Square columns

BENCHES

- With benches;
- Without benches.

TERRACE FLOOR FOR OPEN GRILL CABIN





Without floor (standard)

With terrace floor

ACCESSORIES



Firewood ring



Grill cover 8 corners



Reindeer hides



Wooden dishes and flatware set**



Grill table safety fence 8 corners*

**Available "Basic", "Optimal" or "Luxury" set.

DRAWINGS



FOUNDATION



- It is very important to have a proper foundation for your Cabin. Therefore, we recommend making the foundation according to the sketches here.
- First, the foundation must be prepared according to the landscape and ground conditions.
- The foundation under the product must be prepared specially, it must be homogeneous, tight and even. It must be ensured that the foundation will not change its properties. We recommend using a concrete foundation. Before the installation of the product, we recommend using hydro isolation for the foundation.
- Consult a local qualified builder or an engineer to prepare a proper foundation, which fits your location.
- Due to the improper foundation, structures may crack. Due to uneven product seating, the geometric shape of the building may change, which can result in twisted doors/windows, or/and a gap may appear. The worst-case scenario the building may collapse.

If you do not follow recommendations for building the base, the product will lose its warranty!

PAINTING

COLOR CARD



EXTERIOR WOOD STAIN COLORS

Water-based, quick drying premium total protection for wood outside. Thin layer varnish – 3 in 1: impregnation, primer, and varnish!



PLEASE NOTE: The colors shown in the catalogue and website may not 100% match the color you will receive. The color of the wood material affects the final color.

PAINTING

COLOR CARD

EXTERIOR WOOD PAINT COLORS



Weather protection, water-based paints. High-performance and environmentally friendly.



PLEASE NOTE: The colors shown in the catalogue and website may not 100% match the color you will receive. The color of the wood material affects the final color.

PAINTING

AUTOMATIC MACHINE SPRAY TECHNOLOGY Benefits

One of the main and most obvious benefits of using a paint machine is the speed and flexibility at which we can suggest our painting service for all of our products. A spray paint machine can get the work done faster and more consistently than manually painting. While the machine works faster, it improving quality too – sprayers produce an even coat of paint, leaving a high-quality finish.

With our painting service from now, we can suggest to our client's maximum flexibility! Not assembled products as Grill cabins, Pavilions, Camping pods, and other products of any size you can order painted too!

PROFESSIONAL SPRAY

The high-quality preservative finish is professionally spray applied in the factory to one side of the wood. The product is treated in your choice of color. You can choose two colors for one product: one for almost all product details and another for finishing details.

STAIN | PAINT

Which type of painting should i Use?

Properly painting and impregnating is one of the most important things to consider when thinking about how to extend your product lifetime.

Paint and natural wood finish instantly spruce up the aesthetics of your product.

The decision you will need to make is if you want to use a water-based wood stain or paint. Both will offer you UV protection. The wood stains will allow the texture of the

wood to show through and many are now available in a vast range of colors, however, paints will give you an intensive color, but will cover the grain and texture of the wood.

USAGE AND MAINTENANCE

USAGE.

- The first time you'll use your Grill the surfaces of the new product that are in direct contact with the flames may create a smoky smell when heating up. We advise to keep the door open during the first use and not to cook until the smell disappears.
- When burning wood we recommend to use Grill table metal safety fence.
- We suggest you to use only firewood or briquettes. Larger burning objects can be added later when the fire is burning well. We advise to use objects no larger than 300 mm.
- A sufficient flow of fresh air is the most essential aspect of smoke exhaustion. At least as much fresh air should come in as goes out with the smoke.
- If the Grill is generating a lot of smoke, open the door of the Grill Cabin and make sure that the wood is dry and without a bark. Put in additional dry wood if needed.
- Keep decorations away from your Grill. Hanging decorations look pretty, but provide fuel for a fire.
- Keep water nearby for flare-ups.
- Keep a fire extinguisher within a couple steps of your Grill. And KNOW HOW TO USE IT!
- **Don't leave a Grill unattended**. Don't allow kids or pets to play near the Grill. Never try to move hot Grill, and remember the Grill will stay hot for at least an hour after its use.
- Do not sleep in a Grill Cabin when the fire is on!
- Use protective gloves when handling hot cooking plates. Never move or service an operating Grill.
- Please note, that the metal Grill may have sharp edges and the steel parts of the Grill heats up when the fire is burning, therefore there is risk to harm or burn yourself.
- Remove ashes from the Grill after they have cooled down.
- Make sure you give yourself time to clean your Grill after each use in order to ensure maximum hygiene and proper functioning.

MAINTENANCE.

You should not forget that wood is a natural material, it changes and moves depending on weather conditions. Large and small cracks, color tone differences and other changes, as well as a changing structure of wood are not defects, but a result of wood growing and a feature of wood as a natural material. Natural wood (not impregnated) becomes grayish after being left untouched for a while, and can turn blue and become moldy. You should immediately process it with wood preservative to protect the wooden parts of our manufactured products.

We definitely recommend that you process the door and windows with a wood preservative, and do it on both sides (inside and outside), because the doors and windows can deform. Also, you should pre-treat the floor panels with a wood preservative, especially the bottom sides of the panels, to which you will no longer have access when the Cabin is assembled. Only this will prevent moisture penetration.

In general, we recommend for the conclusive finishing a weather protection paint that will protect wood from moisture and UV radiation after the Cabin is assembled. Consult a specialist regarding paints suitable for unprocessed softwood and follow the paint manufacturer's

instructions. Your Grill Cabin service life will be much longer after it will be properly painted. **We** recommend that you inspect your Cabin thoroughly once every six months.

Customer should make sure that air circulation is working in winter as well. It means that air pipes are open all year around and that moisture gets out from the product (through chimney). Customer should also make sure that product's roof is not covered by snow. A layer of snow cannot be thicker than 20 cm on the roof and the flue should never be covered by snow or closed manually.



Misko 25, LT-85302 Venta, Lithuania info@vikingindustrier.com

www.vikingindustrier.com